



SPECIAL CARE: To prevent scratches or damage to the helmet, when handling, always use a stable surface and cover with a soft towel or similar material. To prevent the lens-screen from being marred or scratched, it is recommended while handling to use gloves or a soft cotton towel.

1-Pull the lens-screen down into the lowest position, and gently pull down until it disengages from the helmet shell.

2-When the lens-screen is lowered out of the shell, gently pull out on the sides until the side clips are disengaged and the screen is released

3-Check to be sure that the anchors of the lens-screen in the interior of the helmet are in the lowered position, insert one end of the screen onto the anchor until you hear a "click", once one side is anchored, proceed with the other side and check that the display moves up and down without difficulty.

